


CHANGING THE GEL CARTRIDGE AND FILTER


<1>

Remove the side plate by turning the spanner vertically. Pull out slightly from the top and lift off.




<2>

Remove the old filter and replace with the new one.




<3>

Remove the old gel (and tube if present)



<4>


Select a new gel cartridge. Push down firmly in the centre of the black cap to release the gel from inside the cap.



For a subtle background fragrance using the Geltronic automatic feed system (Gels last up to 2 months depending on machine settings, temperature etc.)


<5>

Remove the black cap only from the cartridge. Carefully place the cartridge in the control ring.



<6>


Remove the white cap and push the gel gently until resistance is felt.
REPLACE THE WHITE CAP



For stronger fragrance (Gels last up to 1 months depending on machine settings, temperature etc.)

<5a>

Remove the end caps from the replacement gel.



<6a>

Place the gel only onto the control ring.



<7>

Replace the side into the front cover and turn the spanner to a horizontal position

<8>

Keep these instructions with the remaining new gels. Keep the spanner in a safe place for future use.

GELS SHOULD BE KEPT OUT OF THE REACH OF CHILDREN